



Tear on perforation to remove instructions from the template then follow the steps below or turn over for flush striker

## CL400 **RECESSED STRIKER** TEMPLATE

- 1 If **closing jamb** is **RECESSED**: cut template to width of recess in closing jamb. If **closing jamb** is **FLAT**: align centre line on template with centre of closing jamb
- 2 Align horizontal line on template with horizontal line on closing jamb
- 3 Mark hole positions for 4 x  $\varnothing 2.5\text{mm}$  ( $3/32''$ ) holes
- 4 Using a sharp pencil, trace around stencil, **keeping to outermost edge of slots**. Remove template and complete rectangles
- 5 Router inner section to depth of 24mm ( $15/16''$ ) from FACE of jamb
- 6 Router outer section to depth of 12.75mm ( $1/2''$ ) from FACE of jamb
- 7 Drill 4 x  $\varnothing 2.5\text{mm}$  ( $3/32''$ ) holes in positions marked to depth of 25mm (1")



↑ ↑  
Tear on perforation to remove instructions from the template then follow the steps below or turn over for recessed striker

## CL400 **FLUSH STRIKER** TEMPLATE

- 1 If **closing jamb** is **RECESSED**: cut template to width of recess in closing jamb. If **closing jamb** is **FLAT**: align centre line on template with centre of closing jamb
- 2 Align horizontal line on template with horizontal line on closing jamb
- 3 Mark hole positions for 4 x  $\varnothing 2.5\text{mm}$  ( $3/32''$ ) holes
- 4 Using a sharp pencil, trace around stencil, **keeping to outermost edge of slots**. Remove template and complete rectangles
- 5 Router inner section to depth of  $20.5\text{mm}$  ( $13/16''$ ) from FACE of jamb
- 6 Router outer section to depth of  $9.25\text{mm}$  ( $3/8''$ ) from FACE of jamb
- 7 Drill 4 x  $\varnothing 2.5\text{mm}$  ( $3/32''$ ) holes in positions marked to depth of  $25\text{mm}$  ( $1''$ )